

A Laboratory Manual for

# **Oil Hydraulics and Pneumatics (2171912)**

7<sup>TH</sup> Semester

Mechanical Engineering



**SAL COLLEGE OF ENGINEERING, OPP. SCIENCE CITY,  
SOLA-BHADAJ ROAD, AHMEDABAD**



## SAL COLLEGE OF ENGINEERING

### CERTIFICATE

*This is certify that Mr. /Ms. \_\_\_\_\_*

*Enrollment No. \_\_\_\_\_ Branch: **Mechanical Engineering** Semester: **VII***

*has satisfactory completed the course in the subject **Oil Hydraulics and Pneumatics (2171912)** in this institute.*

*Date of Submission: - \_\_\_\_\_*

Staff In-charge

Head of Department



# **SAL COLLEGE OF ENGINEERING**

**DEPARTMENT OF MECHANICAL ENGINEERING**

**B.E. SEMESTER: - VII**

## **OIL HYDRAULICS AND PNEUMATICS (2171912)**


### **LIST OF EXPERIMENTS**

<b>Sr. No.</b>	<b>Title</b>	<b>Date of Performance</b>	<b>Date of Submission</b>	<b>Sign</b>	<b>Remark</b>
1	To Study Hydraulic Power Pack System				
2	Extend-Retract And Stop System Of Linear Actuators				
3	Regenerative Circuit For Hydraulic System				
4	Speed Control Circuit: Meter In, Meter Out				
5	Sequencing Circuit For Hydraulic System.				
6	Use Of Solenoid Operated Direction Control Valve For Hydraulic System				
7	Reciprocating Motion Of Single & Double Acting Cylinder				
8	Speed Control Circuit For Pneumatic System				
9	Automatic To & Fro Motion Of Pneumatic Linear Actuator				
10	Sequencing Circuit For Pneumatic Circuit				

## EXPERIMENT 1

### TO STUDY HYDRAULIC POWER PACK SYSTEM

**AIM :** To Study Hydraulic Power - Pack.




- ✓ Tank
- ✓ Breather
- ✓ Oil Level Indicator
- ✓ Inlet Filter
- ✓ Pump
- ✓ Motor
- ✓ Pressure Line Manifold
- ✓ Pressure Gauge
- ✓ Pressure Relief Valve
- ✓ Return Line Manifold
- ✓ Return Line Filter

## EXPERIMENT 2


# EXTEND-RETRACT AND STOP SYSTEM OF LINEAR ACTUATORS

**AIM :** To Study 4/2 Way DC Valve Using Single Acting Cylinder.




- ✓ Make connection as per the circuit.
- ✓ Switch ON the hydraulic power pack as explained in experiment.
- ✓ The moment you switch ON the system hydraulic cylinder starts extending.
- ✓ Operate the lever of 4/2 way DC valve and cylinder starts moving in reverse direction.
- ✓ Release the lever and it goes to original position due to spring inside the valve.

**AIM :** To Study 4/3 Way DC Valve Using Double Acting Cylinder.




- ✓ Make connection as per the circuit.
- ✓ Switch ON the hydraulic system.
- ✓ If lever is in central position no movement of cylinder takes place.
- ✓ Operate the lever ( push or pull ) and see the effects.

**AIM :** To Control Double Acting Cylinder by 4/2 Way DC Valve.



- ✓ Make connection as per the circuit.
- ✓ Switch ON the hydraulic system.
- ✓ The moment you switch ON the system hydraulic cylinder starts extending.
- ✓ Operate the lever cylinder starts moving in reverse direction.
- ✓ Release the lever, it goes to original position due to spring inside the valve.

**AIM:** To Control Single Acting Cylinder by 4/2 Way DC Valve.




- ✓ Make connection as per the circuit.
- ✓ Switch ON the hydraulic system.
- ✓ The moment you switch ON the system hydraulic cylinder starts extending.
- ✓ Operate the lever cylinder starts moving in reverse direction.
- ✓ Release the lever, it goes to original position due to spring inside the valve.



## EXPERIMENT 3



### REGENERATIVE CIRCUIT

**AIM:** Regenerative Circuit.



- ✓ Make connections as shown in the circuit.
- ✓ Switch on the system.
- ✓ Operate DCV
- ✓ Note that now cylinder moves faster in forward direction as compared to normal connections to DCV.
- ✓ Cylinder rod end connection is connected to pressure line.
- ✓ As both the sides are pressurized cylinder starts extending as Capacitive side has larger cross sectional area compared to rod end side.
- ✓ Speed also increases as rod end outlet flow is added back to cap end.
- ✓ Force in this circuit is reduced in forward direction which is equivalent to rod area multiplied by system pressure.
- ✓ This circuit with little modifications is used where greater speeds are required and force requirement is not critical.


**AIM: Regenerative Circuit Using Solenoid Valve**



## EXPERIMENT 4


## SPEED CONTROL CIRCUIT: METER IN, METER OUT

**AIM :** To Study Meter - In Flow Circuit.



- ✓ Make connection as per the circuit.
- ✓ Operate DCV to move cylinder in either direction.
- ✓ Adjust flow control and notice the change in speed.
- ✓ Here you are controlling ( Metering ) the oil flow entering into the cylinder. That is why it is called meter - in flow.
- ✓ This type of control is used when load is opposing the motion of cylinder.


**AIM: To Study Meter Out Circuit**



## EXPERIMENT 5

### SEQUENCING CIRCUIT



**AIM :** To study sequence valve.



- ✓ Make connections as shown in the circuit.
- ✓ Keep the sequence valve spring fully open.
- ✓ Start the system.
- ✓ You will notice the movement of cylinder / motor when you operate DCV.
- ✓ If you want motor to operate only when cylinder is fully extended or retracted start screwing in sequence valve.
- ✓ At a particular stage movement of motor will stop.
- ✓ Unscrew the valve by quarter / half / one turn till motor starts rotating.
- ✓ Operate DCV. Now you will notice that first cylinder moves fully forward / retracts fully and then only motor rotates.
- ✓ Sequence valve is used to control sequence of motions.
- ✓ This circuit can be used for clamping of workpiece and the rotation of chuck.


## EXPERIMENT 6


## USE OF SOLENOID OPERATED DIRECTION CONTROL VALVE

CONTROL OF DOUBLE ACTING CYLINDER USING 4/2 SINGLE SOLENOID VALVE

## EXPERIMENT 7

## RECIPROCATING MOTION OF SINGLE &amp; DOUBLE ACTING CYLINDER

**Exercise 1.** Operation of a single acting cylinder


**Exercise 2.** Operation of a double acting cylinder




## EXPERIMENT 8

### SPEED CONTROL CIRCUIT

**Exercise 9.** Controlling the speed of a double acting cylinder using METERING IN valve




**Exercise 10.** Controlling the speed of a double acting cylinder using METERING OUT valve

## EXPERIMENT 9

AUTOMATIC TO & FRO MOTION OF PNEUMATIC LINEAR  
ACTUATOR

**Exercise 11.** Automatic operation of a double acting cylinder in single cycle  
using roller lever valve and memory valve



## EXPERIMENT 10

### SEQUENCING CIRCUIT

**Exercise 13.** Single cycle automation of multiple cylinders in sequence  
(Sequence of motion : A+B+A-B-).

